

XUSL4E – How to increase OSSD

Wiring diagram association XUSL4E + 2
XPSECME/PE contact extension units
providing 4 or 8 safety circuits (2x2 or 2x4) in
a standalone solution

Simply easy!TM



Telemecanique

Sensors

XUSL4E – How to increase OSSD number

- Wiring diagram

- Response time of XPSECME unit <40ms

References

Description	Connection	Number of safety circuits	Additional outputs	Supply	Reference
Safety modules for extending the number of safety contacts, for use with XPSbase modules	Captive screw clamp terminals Terminal block removable from module	4	2	~ and = 24 V	XPSECME5131P
Spring terminals Terminal block removable from module		4	2	~ and = 24 V	XPSECME5131C

